




WIRING DIAGRAM



WIRING DIAGRAM



WIRING DIAGRAM



- 1 Operator ZT4
- 2 Flasing beacon (optional)
- 3 Antenna (with 4,5 coaxial cable)
- 4 Receiving photocell
- 5 Emitting photocell
- 6 Internal keypad (optional)

- 7 Key switch, touch-sensetive keypad (both optional)
- 8 Electronic unit + radio receiver
- 9 Electronic lock (optional)
- 10 Main ON/OFF switch (responsability of installin electrician)

